

# INSTALLATION GUIDE MODEL #: EOL-WL12BLK-1030e



# Questions?

For customer service please call us at 1-888-743-5766 Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday

### PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION

## WARNINGS

• Risk of fire / electrical shock

• LED Fixture installation requires knowledge of luminaire electrical systems.


• Risk of electric shock – disconnect power at source before installation

• Do not make or alter any open holes in an enclosure of wiring or electrical components during installation.

• If lamp or luminaire exhibits abnormal operation (buzzing, flickering, minimal light, etc.), turn off power, remove fixture and contact us. For more information please visit www.eurilighting.com or call our toll-free number 1-888-743-5766.

## CAUTIONS

- Do not use with dimmers.
- Do not look directly at the operating LED Fixture.
- Do not touch this product with wet hands.
- Do not disassemble, repair or alter lamp.
- Designed for outdoor applications only.
- Suitable for wet locations.
- The luminaires shall be grounded.
- Be careful not to touch the lamp pins to the metal housing when installing.
- This Device is not intended for use with emergency exits or emergency lights.



#### **INSTALLATION INSTRUCTIONS**

- 1. Install mounting plate to Junction Box.
- 2. Use wire cap(7) connect wire.

3. Insert screws(5) through holes on the backplate(4),

tighten the screws nuts(6).

4. Done.