

INSTALLATION GUIDE

LED Fixtures | Outdoor Wall Light Series

Bulkhead Class


MODEL #: EOL-WL13BLK-2050e / EOL-WL14WH-2050e



Questions?

For customer service please call us at 1-888-743-5766 Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday

PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION




WARNINGS

- · Risk of fire / electrical shock
- LED Fixture installation requires knowledge of luminaire electrical systems.
- Risk of electric shock disconnect power at source before installation
- Do not make or alter any open holes in an enclosure of wiring or electrical components during installation.
- If lamp or luminaire exhibits abnormal operation (buzzing, flickering, minimal light, etc.), turn off power, remove fixture and contact us. For more information please visit www.eurilighting.com or call our toll-free number 1-888-743-5766.

CAUTIONS

- Do not use with dimmers.
- Do not look directly at the operating LED Fixture.
- Do not touch this product with wet hands.
- Do not disassemble, repair or alter lamp.
- Designed for outdoor applications only.
- · Suitable for wet locations.
- The luminaires shall be grounded.
- Be careful not to touch the lamp pins to the metal housing when installing.
- This Device is not intended for use with emergency exits or emergency lights.



INSTALLATION INSTRUCTIONS

- 1. Screw in the fixture mounting screws (4) into the cross bar (3).
- 2. Install the mounting plate(3).
- 3. Use wire nut connect wire.
- 4. Install mounting screw (4) to fixture body (10) and tighten the screw nut (5).
- 5. Put the glass (11) on the fixture body (10).
- 6. Insert the screws(13) into the holes of body (12) (13) and tighten them.