

# **INSTALLATION GUIDE** MODEL #: EOL-WL18BLK-1030e


Lantern Class



## Questions?

For customer service please call us at 1-888-743-5766






## **WARNINGS**

- · Risk of fire / electrical shock
- LED Fixture installation requires knowledge of luminaire electrical systems.
- Risk of electric shock disconnect power at source before installation
- Do not make or alter any open holes in an enclosure of wiring or electrical components during installation.
- If lamp or luminaire exhibits abnormal operation (buzzing, flickering, minimal light, etc.), turn off power, remove lamp and contact us. For more information please visit www.eurilighting.com or call our toll-free number 1-888-743-5766.

#### **CAUTIONS**

- Do not use with dimmers.
- Do not look directly at the operating LED Tube.
- Do not touch this product with wet hands.
- Do not disassemble, repair or alter lamp.
- Designed for outdoor applications only.
- Suitable for wet locations.
- The luminaires shall be grounded.
- Be careful not to touch the lamp pins to the metal housing when installing.
- · This Device is not intended for use with emergency exits or emergency lights.

#### INSTALLATION INSTRUCTIONS



3. Install the fixture body and screw nut